


USER'S GUIDE

YP11528(MULTI FUNCTION SPORT WATCH WITH TOUCH PAD)

-  Touch Pad
-  EL Backlight
-  Stopwatch
-  Dual Time
-  Countdown Timer
-  Alarm
-  30 Years Calendar
-  Chime
-  100M Water Resistant
-  Battery CR2025

BUTTONS

- Button and touch pad operation are indicated using the letters shown in the illustration.




- A -- Reset
- B -- Mode
- C -- Start / Stop
- D -- EL/Unlock

ATTENTION

1. Never try to open the case or remove its back cover.
2. Do not operate buttons underwater.
3. Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
4. Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
5. Avoid exposing the watch to temperature extremes.
6. Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
7. Avoid to wear the watch in electromagnetic, static conditions.


DISPLAY

- The screen shown in below:



UNLOCK

- In any mode, press "D" about 3 seconds to on (unlocked)/off(locked)the touch pad function.



- The EL backlight function is none in the unlocked status.
- If the touch pad function has an error(such as strong EMI or others), it doesn't means the malfunction with the watch. Please press "D" 3 seconds to come back locked status, then press "D" 3 seconds again.

MODE SELECTION

- In the unlocked status, touch "B" to change mode to mode in the following sequence: Timekeeping Mode → Stopwatch Mode → Countdown Mode → Alarm Mode → Dual Time Mode.

a TIMEKEEPING

- 12/24H Format;
- Day of week, Month, Date , Hour, Minutes, Seconds ;
- 30 years Calendar (2010 ~ 2039).



b STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00"00 ~ 23:59'59".



c COUNTDOWN

- Countdown timer range: 23:59'59" ~ 0'00"00.



d ALARM

- Hourly time signal;
- The alarm sounds at the preset time each day.



e DUAL TIME

- The time for other time zone.



a TIMEKEEPING

12/24H Format

- In the timekeeping mode, touch "C" to switch between 12/24H formats.



Time Setting

1. In the timekeeping mode, touch "A" the seconds to flash(flashing indicated in set mode);



2. Touch "C" to reset the seconds;



3. Touch "B" change to the next selection;



4. Touch "C" to increase the number, touch and hold to change at high speed;



5. Repeat step 3 and 4, the selection in the following sequence: Seconds - Hour - Minutes - Year - Month -Date;

6. Touch "A" to exit the set state, after you set (The day of week is auto displayed in accordance with year, month and date setting).



b STOPWATCH

A Lap Time



1. In the stopwatch mode, touch "C" to start the stopwatch;



2. Touch "C" again to stop the stopwatch;



3. Touch "A" to reset the stopwatch.



Split Time



1. In the stopwatch mode, touch "C" to start the stopwatch;



2. Touch "A" to display the split time, stopwatch timing continues internally;



3. Touch "A" to clear the split time and to continue time measurement;



4. Repeat step 2 and 3, you can measure the multi split time;

5. Touch "C" to stop the stopwatch.

c COUNTDOWN

- When the countdown reaches zero, the alarm sounds for about 60 seconds and press "D" to break it.

Countdown Time Setting

1. In the countdown mode, touch "A" the hour to flash (flashing indicated in set mode);



2. Touch "C" to increase the hour, touch and hold to increase at high speed;



3. Touch "B" change to the next selection;



4. Touch "C" to increase the number, touch and hold to change at high speed;



- Repeat step 3 and 4, the selection in the following sequence: Hour – Minutes – Seconds;

6. Touch "A" to exit the set state, after you set.

Use The Countdown Timer

1. Touch "C" to start the countdown;



2. Touch "C" again to pause the countdown.

d ALARM

- The alarm sounds at the preset time each day for about 60 seconds, press "D" to break it.


Alarm and Chime

- In the alarm mode, touch "C" to on/off the alarm and chime in the following sequences:
Alarm & Chime off – Alarm on – Chime on – Alarm & Chime on.



Alarm Setting

1. In the alarm mode, touch "A" the hour to flash (flashing indicated in set mode);



2. Touch "C" to increase the hour, touch and hold to increase at high speed;



3. Touch "B" to select the minutes;



4. Touch "C" to increase the minutes, touch and hold to increase at high speed;



5. Touch "A" to exit the set state, after you set.

e DUALTIME

Dual Time Setting

1. In the dual time mode, touch "A" the hour to flash (flashing indicated in set mode);



2. Touch "C" to increase the hour, touch and hold to increase at high speed;



3. Touch "B" to select the minutes;



4. Touch "C" to change the minutes (touch once change 30 minutes);



5. Touch "A" to exit the set state, after you set.

BACKLIGHT

- The backlight that uses an EL (electroluminescent) cause the display to glow for easy reading in the dark.

Use EL Backlight

- In the locked status, press "D" to illuminate the display about 3 seconds.

